

HP-Ge Crystal Growth at USD

Sanjay Bhattarai, Narayan Budhathoki, Kungming Dong, Austin Warren, and
Dongming Mei

The University of South Dakota

May 14, 2024



This work is done under the collaboration PIRE-GEMADARC. It was sponsored by
NSF OISE-1743790, NSF PHYS 2310027, and NSF PHYS 2117774.



PIRE
GEMADARC




UNIVERSITY OF
SOUTH DAKOTA

MOTIVATIONS

- Conduct research and development on high-purity germanium crystal (HP-Ge) growth techniques essential for the production of HP-Ge germanium detectors
- Enhance crystal quality by investigating and optimizing the crucial factors affecting the crystal growth process
- Cultivate large HP-Ge crystals, transform them into functional detectors, and conduct in-depth analyses to understand detector behavior, with a particular emphasis on rare event detection

Why Germanium?

- Low energy threshold
- Excellent energy resolution
- Relatively simple cooling systems
- Excellent event/background discrimination power
- For neutrinoless beta decay ^{76}Ge acts as both source and detector with relatively low half time for decay



- More recoil (more energetic interaction) for Ge; more counts for Xe.
- Counts can be increased by increasing detector size.

Requirements of Germanium Detectors

- Depletion depth d of a planar detector

$$d = \sqrt{2 \epsilon V_0 / eN}$$

here, V_0 is the applied bias voltage, N is the net impurity concentration in the crystal, e is the charge of, electron, and ϵ is the dielectric constant of Ge

- Net Impurity concentration should be $\sim 10^{10}/\text{cm}^3$ for full depletion of about a 1 cm thick detector
- Dislocation density 300-10000/ cm^2 ; Otherwise, divacancy-hydrogen complex (V_2H) or dislocation itself will work as charge trapping center (1)
- Homogenous Impurity concentration along the detector
- **Ton-scale Ge-based experiments and large-size crystals are needed to improve the sensitivity and detection efficiency**

1 (DIVACANCY HYDROGEN COMPLEXES IN DISLOCATION -FREE HIGH -PURITY GERMANIUM, E. E. Haller, G. S. Hubbard, W. L. Hansen, and A. Seeger)

Material Preparation



Germanium ingots ready for etching



Crucible and glass tubes being cleaned with hydrogen peroxide

5/13/24



Etching ingots with strong acid, HF: HNO₃ (1:3)




Drying with Nitrogen before loading in the chamber

6

Sanjay Bhattarai, USD

Procedure

- Seed crystal (100) Ge) is dipped into the molten Ge and withdrawn slowly, while maintaining the temperature of melt just above the melting point.
- The rate of crystal withdrawal (pull speed) and temperature (applied power) of melt are adjusted to control the growth of the crystal.



Diameter Control

$$D = \sqrt{\frac{4 \frac{dw}{dt}}{p \pi \rho_s + \left(\frac{dw}{dt} \cdot \rho_s\right) / R^2 \rho_L}}$$




$\frac{dw}{dt}$ = growth rate

ρ_s = density of solid germanium

ρ_L = density of liquid germanium

R = radius of the crucible

p = pull rate



Impurity Segregation

$$C(g_i) = C_B(g_i) + C_{Al}(g_i) + C_{Ga}(g_i) + C_P(g_i)$$

- $C(g_i)$ = Net impurity concentration at position g_i
- $C_B(g_i)$ = Impurity concentration of **boron** at position g_i
- $C_{Al}(g_i)$ = Impurity concentration of **aluminium** at position g_i
- $C_P(g_i)$ = Impurity concentration of **phosphorous** at position g_i
- $C_{Ga}(g_i)$ = Impurity concentration of **galium** at position g_i

Scheil's equation

$$C = C_0 k_{eff} (1 - g)^{K_{eff}-1}$$

Where, g = the solidified fraction at different positions: 0.005 at the neck, 0.15 at S1, 0.45 at S2, 0.75 at S3, and 0.995 at the tail.

k_{eff} = effective seggration coefficient = $k_0 + (1 - k_0) \exp\left(-\frac{f\delta}{D}\right)$

Where, k_0 is equilibrium seggration coefficient, f = growth rate , D = diffusion coefficient of impurity in germanium melt.

$$\delta = 1.6D^{\frac{1}{3}}v^{\frac{1}{6}}w^{-\frac{1}{2}}, v = \text{kinematic viscoity}, w = \text{rotation rate of crystal}$$

position	Net Impurity (/cm ³)	Resistivity (Ω cm)	Mobility (cm ² /Vs)
Neck	1.01×10^{11}	5.40×10^2	3.24×10^4
S1	6.31×10^{10}	3.74×10^3	3.63×10^4
S2	1.55×10^{10}	4.92×10^3	3.48×10^4
S3	-1.13×10^{11}	3.80×10^2	2.14×10^4
Tail	-1.04×10^{13}	6.32×10^1	1.41×10^4

Wang, G.; Amman, M.; Mei, H.; Mei, D.; Irmscher, K.; Guan, Y.; Yang, G. Crystal growth and detector performance of large size high-purity Ge crystals. *Mater. Sci. Semicond. Process.* 2022, 39, 54–60.

Bhattarai S, Mei D, Budhathoki N, Dong K, Warren A. Investigating Influential Parameters for High-Purity Germanium Crystal Growth. *Crystals.* 2024; 14(2):177. <https://doi.org/10.3390/cryst14020177>

Results



$$2.84C_{0B} + 0.19C_{0Al} + 0.2C_{0Ga} - 0.10C_{0P} = 1.01 \times 10^{11},$$

$$2.12C_{0B} + 0.20C_{0Al} + 0.21C_{0Ga} - 0.11C_{0P} = 6.31 \times 10^{10},$$



$$0.22C_{0B} + 0.58C_{0Al} + 0.6C_{0Ga} - 0.35C_{0P} = -1.13 \times 10^{11},$$

$$0.00014C_{0B} + 13.89C_{0Al} + 13.87C_{0Ga} - 11.86C_{0P} = -1.00 \times 10^{13},$$



The initial concentration (C_0) of B, Al, Ga and P for this crystal were found to be $3.87 \times 10^{10}/\text{cm}^3$, $2.21 \times 10^{11}/\text{cm}^3$, $7.13 \times 10^{11}/\text{cm}^3$ and $1.89 \times 10^{12}/\text{cm}^3$ respectively.



Dislocation Measurement




➤ Dislocations observation under microscope




Detector-Grade Crystals Summary

Mass of Detector-grade Crystals



Size of Detector-grade Crystals




- 36.1kg detector grade crystals at USD:
 - 43 detector grade crystals;
 - Impurity level: $3.77 \times 10^9 \sim 7 \times 10^{10} / \text{cm}^3$.
 - Average diameter: 8.5 cm.
 - Average thickness: 2.5 cm.



- Mass: 2247g
- Diameter: 10cm
- Thickness: 5.4cm
- Impurity Level: $2.06E10^{10}$ (top)
 $2.68E10^{10}$ (bottom)

Energy Spectrum of Cs-137



- Energy spectrum from a Cs-137 source measured with the detector USD-R03. The source was positioned facing the detector top. The bias voltage of -2500 V was applied to the bottom electrical contact on the detector while the signals were measured from the top.

Conclusions

- At USD, we have successfully built a production chain that can purify Ge raw materials, grow detector-grade HP-Ge crystals, and fabricate them into Ge detectors
- A well-controlled segregation method and thermal field are used to control the distribution of impurities during crystal growth to meet the requirements for detector-grade Ge crystals
- We investigated some essential parameters like impurity segregation to improve the quality of the crystal; we will continue to investigate and develop the influential parameters for the entire HP-Ge development chain

Thanks!